

Additional Rules for working with S2 Pathogens:

- All work with S2 pathogens must be done in the clean bench marked "S2 Pathogens".
- Separate lab coats are required to be worn in the S2 bacterial pathogen room.
- Wearing of sleeves is required for working under the hood with S2 pathogens.
- Must wear lab coat, closed-toed shoes and have hair restrained (not loose) to enter bacterial room.
- Restrict work with S2 pathogen to the clean bench and minimize external work as much as possible.
- When working outside of the hood with S2 pathogen, must wear one time use coat, safety goggles, shoe coverings and FP2 mask.
- Thoroughly disinfect working area with Meliseptol, allow to react for 60 sec.
- Liquid waste jars must be clearly marked with "S2 Waste".
- All waste in the biosafety waste bins that contain S2 pathogens must be double bagged, labeled with "S2" and sealed with autoclave tape before placing into the bin for autoclaving. Transport in the Biosafety bin to the autoclave room.
- All waste bags must be double bagged.
- After handling S2 pathogens, always throw away gloves and wash hands thoroughly before leaving the room.
- Use 1:1 ratio of Meliseptol to treat spills. If spill occurs outside of clean bench, treat spill and notify area responsible person.
- Transport of S2 material outside of room in transport boxes only.